


(1) H14258 ANGLE METER WITH COMPRESSION
INLET OR STD CURB STOP

N O T E:

IF THE ARV ASSEMBLY IS LOCATED WHERE GROUND WATER
WILL INTERFERE WITH THE AIR DISCHARGE PIPE, A STAND
PIPE MUST BE INSTALLED ABOVE GROUND WITH A STRAINER
OR A PIPE INSTALLED FROM THE METER BOX TO A CATCH
BASIN.



CITY OF EDMONDS

REVISIONS

APPROVED BY	DATE
D. GEBERT	10/6/03

STANDARD DETAIL

ARV ASSEMBLY (TYPE 2)

DATE	7/24/01	SCALE	NTS	DWG NO.	E7.4
------	---------	-------	-----	---------	------